



Sturdy and durable, BKT label printing scales are ideal for manufacturing, shipping and receiving, packing and distribution warehouses. The BKT has a built in printer that can print weight, QR codes, bar codes and labels in numerous languages. Software is included for personalized label design and formatting on computers. BKT scales consist of a sturdy ABS plastic indicator, cast aluminium base, and easy-to-clean stainless steel platform. Operation is simple using six buttons on the indicator, and results are readily visible on the backlit LCD. The indicator can be placed on a bench or attached to the included pillar. The BKT offer three platform sizes to accommodate large or small objects. RS-232 interface provide speedy connection to computers and printers.

**Quickly produce custom labels and bar codes with the built-in printer**



## Features

- Vivid, backlit LCD easily visible in any lighting conditions
- Programmable backlight can be set to "always on," "always off" or "light only when weighing"
- Color-coded keys facilitate quick recognition of the most frequently used buttons
- Level indicator and adjustable feet ensure proper balance setup for optimum weighing results
- Large, grade 304 stainless steel pan allows swift cleaning
- RS-232 interface is available to provide speedy connection to computers and printers
- Rugged construction stands up to industrial use
- Sealed keypad protects against dirt and spills
- Overload protection helps prevent damage to internal components
- Built in printer can print weight, QR codes, bar codes and labels in numerous languages
- Checkweighing with audible alarm
- Memory accumulation totals results
- Parts counting optimization automatically refines piece weight as parts are added
- Selectable digital filtering helps minimize effects of vibration and disturbances
- Zero-tracking feature ensures display returns to zero reading
- Easy label creation/editing is possible on a computer using the included software
- Rechargeable battery included for operation almost anywhere
- Programmable auto power-off to save energy

## Applications

- Weighing
- Parts counting
- Percentage weighing
- Checkweighing
- Dynamic / animal weighing
- Accumulation
- Display hold
- Peak hold
- Barcode / label printing

## About ADAM:

For more than 45 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

# BKT Label Printing Scales



Model	BKT 16a	BKT 35a	BKT 65a	BKT 130a	BKT 260a	BKT 165a	BKT 165aH	BKT 330a	BKT 330aH	BKT 660a	BKT 1320a
<b>Capacity</b>	16lb / 8kg	35lb / 16kg	65lb / 30kg	130lb / 60kg	260lb / 120kg	165lb / 75kg	165lb / 75kg	330lb / 150kg	330lb / 150kg	660lb / 300kg	1320lb / 600kg
<b>Readability</b>	0.0005lb / 0.2g	0.001lb / 0.5g	0.002lb / 1g	0.005lb / 2g	0.01lb / 5g	0.01lb / 5g	0.005lb / 2g	0.02lb / 0.01kg	0.01lb / 5g	0.05lb / 0.02kg	0.1lb / 0.05kg
<b>Repeatability (S.D.)</b>	0.0005lb / 0.2g	0.001lb / 0.5g	0.002lb / 1g	0.005lb / 2g	0.02lb / 10g	0.01lb / 5g	0.005lb / 2g	0.02lb / 0.01kg	0.01lb / 5g	0.05lb / 0.02kg	0.1lb / 0.05kg
<b>Linearity (+/-)</b>	0.001lb / 0.4g	0.002lb / 1g	0.005lb / 2g	0.01lb / 5g	0.02lb / 10g	0.02lb / 10g	0.01lb / 4g	0.05lb / 0.02kg	0.05lb / 10g	0.1lb / 0.04kg	0.2lb / 0.1kg
<b>Pan Size</b>	11.8"x15.7" / 300x400mm						15.7"x19.7" / 400x500mm				23.6"x31.5" / 600x800mm
<b>Weighing Units</b>	g, kg, ct, lb, oz, dr, mm, T, tonne										
<b>Stabilization Time (sec)</b>	2										
<b>Interface</b>	RS-232										
<b>Calibration</b>	External calibration										
<b>Display</b>	Backlit LCD with 1.3" / 34mm -high digits										
<b>Power Supply</b>	12VDC 3A adapter / Internal rechargeable battery										
<b>Operating Temperature</b>	-10° to 40°C / 14° to 104°F										
<b>Housing</b>	ABS plastic indicator with die-cast aluminum base										
<b>Overall Dim.</b>	11.8"x20.5"x26.8" / 300x520x680mm (wxdxh)						15.7"x24.4"x33.9" / 400x620x860mm (wxdxh)				23.6"x37"x35.4" / 600x940x-900mm (wxdxh)
<b>Net Weight</b>	18.7lb / 8.5kg						29.8lb / 13.5kg				58.4lb / 26.5kg

## Accessories

Item number	Description
3074010266	RS-232 cable (null-modem)
600002028	AdamDU Data Collection Program
700200107	Casters / wheels (set of 4)
700660290	Calibration certificate
700660288	Calibration certificate (IHS, LHS, AFK 1320, GFK 1320, PTM)

## Key Accessories



### AdamDU Data Collection Program

Adam DU software connects a balance to the laboratory network, helping to achieve seamless data collection, transfer and analysis. DU features an easy-to-use interface with a main command window, allowing users to quickly collect information from up to eight Adam balances simultaneously using RS-232 or USB connections.



### Casters / wheels (set of 4)

Optional caster wheels provide easy mobility for bench and floor scales. A brake lock prevents movement during use.

Supplied by

[www.adamequipment.com](http://www.adamequipment.com)

Adam Equipment follows a policy of continuous improvement and reserves the right to change specification and pricing without notice. Adam Equipment's standard terms and conditions of sale apply. Errors and omissions excepted.  
©2019 Adam Equipment. EN-812 11/14/019