

GBK Mplus Approved Bench Checkweighing Scales



With its high-quality grade aluminum cast platform, the OIML-approved GBK Mplus stands up to the demanding nature of rigorous industrial and repetitive commercial warehouse applications effortlessly. Compact in design, the GBK Mplus fits easily on tabletops where space availability may be restricted and is ideal for parts counting, checkweighing or routine weighing, providing its user with a convenient yet versatile bench weighing scale that can complete a wide range of tasks. A large backlit LCD that changes colour in checkweighing mode to quickly notify the user of pre-set limits contributes to the versatility and easy user operation of the GBK Mplus. In addition, the pillar-mounted display can be used without the pillar for flexible positioning. Hardened electronics and high levels of protection make the GBK Mplus a suitable choice, especially in environments with large amounts of static present. Combined with the GBK Mplus' resolution, it can be verified up to 3,000 divisions, which makes this bench scale highly accurate and precise. The GBK Mplus' intuitive software helps save time and reduces errors when logging data. Powered by mains power cord or the built-in rechargeable battery, the GBK Mplus can operate almost anywhere.

The all-in-one solution for demanding industrial and manufacturing tasks

Features

- Hardened electronics meet rigorous latest OIML approval standards
- Resolution that can be verified up to 3,000 divisions
- Vivid, backlit LCD easily visible in any lighting conditions
- Backlit display changes color for quick notification of checkweighing limits
- Programmable backlight can be set to "always on," "always off" or "light only when weighing"
- RS-232 interface is available to provide speedy connection to computers and printers
- Checkweighing with audible alarm
- Parts counting optimization automatically refines piece weight as parts are added
- Parts counting with freely selectable sample sizes
- Capacity tracker built into display for easily monitoring possible overloads
- Color-coded keys facilitate quick recognition of the most frequently used buttons
- Rugged construction stands up to industrial use
- Overload protection helps prevent damage to internal components
- Sealed keypad protects against dirt and spills
- Level indicator and adjustable feet ensure proper balance setup for optimum weighing results
- Selectable language for printing
- Selectable digital filtering for animal/dynamic weighing enables consistent results for moving subjects
- Zero-tracking feature ensures display returns to zero reading
- Rechargeable battery included for operation almost anywhere
- Programmable auto power-off to save energy

Applications

- Weighing
- Parts counting
- Percentage weighing
- Checkweighing
- Check counting
- Dynamic / animal weighing
- Net total weighing
- Display hold

About ADAM:

For more than 45 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

GBK Mplus Approved Bench Checkweighing Scales

Model	GBK 6Mplus	GBK 15Mplus	GBK 30Mplus	GBK 60Mplus	GBK 150Mplus
Maximum Capacity	6kg	15kg	30kg	60kg	150kg
Readability	2g	5g	0.01kg	0.02kg	0.05kg
Repeatability (S.D.)	2g	5g	10g	20g	50g
Linearity	4g	10g	20g	40g	100g
Pan size	300x400mm				
Weighing units	g, kg				
Stabilisation time (sec)	2				
Interface	RS-232				
Calibration	External calibration				
Display	Backlit LCD with 25mm-high digits				
Power Supply	Power Cord / Internal rechargeable battery				
Operating Temp.	-10C to 40C				
Housing	ABS plastic indicator with aluminium cast base				
Overall Dims.	300x520x660mm (wxdxh)				
Net Weight	7.4kg				
Approvals	OIML				

Accessories

Item Number Description

- 3052010526..... In-use cover
- 1120011156 ATP thermal printer
- 3126011263 ATP thermal printer paper
- 3126011281 ATP thermal printer paper (pack of 10)
- 1120014641 AIP impact printer
- 3074010266 RS-232 cable
- 3074010507..... RS-232 to USB adapter
- 600002028 AdamDU Data Collection Program
- 700660290 Calibration certificate
- 700200107..... Casters / wheels (set of 4)
- 2050013351..... Indicator stand

Key Accessories



Indicator Stand

To stabilize a freestanding indicator that is separated from a scale, attach it to the indicator stand for reliable support. Sturdy aluminium construction is also lightweight, so the stand is easy to transport.



AIP Impact Printer

Easy to use, the AIP high-speed dot matrix printer connects with any device containing an RS-232 or USB interface. Communication is smooth and fast, as the AIP automatically detects a scale's settings. AIP features durable ABS plastic construction and is simple to use, as it operates with just an on/off switch and a paper feed button.

Supplied By: