



Offering an all-in-one solution, the PTT Pallet Truck Scale combines the power of a 5000lb/2000kg capacity heavy-duty pallet truck scale with the convenience of a built-in label printer. The PTT features solid steel pallet forks, wheels that swivel for easy movement and an audible alarm that indicates when capacity is exceeded.

A versatile and practical choice, PTT is ideal for transporting heavy objects and goods on pallets, as well as recordkeeping and inventory. An internal rechargeable battery allows long periods of continual use, while color-coded keys and a large LCD display with 1.3"/34mm digits provide visibility under even the poorest of lighting conditions.

The PTT also features a range of integrated applications, including accumulation, hold, parts counting and checkweighing. The PTT includes easy-to-use PC software that allows the 2"/50mm-wide printed labels to be quickly tailored to any requirement with the addition of custom logos, images, barcodes and QR codes.

## Weigh, Print and Customize with the Heavy-Duty PTT Pallet Truck Scale

### Features

- Built in printer can print weight, QR codes, bar codes and labels in numerous languages
- Vivid, backlit LCD easily visible in any lighting conditions
- Programmable backlight can be set to "always on," "always off" or "light only when weighing"
- Color-coded keys facilitate quick recognition of the most frequently used buttons
- RS-232 interface provides speedy connection to computers and printers
- Rugged construction stands up to industrial use
- Sealed keypad protects against dirt and spills
- Checkweighing with audible alarm
- Parts counting optimization automatically refines piece weight as parts are added
- Rechargeable battery included for operation almost anywhere
- AC adapter included
- Wheels swivel, allowing easy movement
- Zero-tracking feature ensures display returns to zero reading

### Applications

- Weighing
- Parts counting
- Percentage weighing
- Checkweighing
- Dynamic / animal weighing
- Accumulation
- Display hold
- Peak hold
- Barcode / label printing

### About ADAM:

For nearly 50 years, professionals worldwide have relied on Adam Equipment for an extensive selection of dependable and affordable weighing equipment. Adam provides the right balance of speed, performance and value.

Model	PTT 5000a
Maximum Capacity	5000lb / 2000kg
Readability	1lb / 0.5kg
Repeatability (S.D.)	2 lb / 1 kg
Linearity (+/-)	1 kg
Fork size	45x6" / 1150x160mm
Weighing units	g, kg, ct, lb, oz, dr, mm, T, tonne
Stabilisation Time (sec)	2
Interface	RS-232
Calibration	External calibration
Display	Backlit LCD with 1.3" / 34mm-high digits
Power supply	12VDC 3A adapter, Internal rechargeable battery
Operating Temperature	14 to 104 °F / -10 to 40°C
Housing	Mild steel base / ABS plastic
Overall Dim.	22 x 60 x 46" / 550 x 1525 x 1175mm (WxDxH)
Net Weight	276lbs / 125kg

## Accessories

Item Number .....	Description
3102311619 .....	In-use wet cover
700400103.....	RS-232 cable
3074010507.....	RS-232 to USB adapter
400005615 .....	Labels - 800 per roll
600002028 .....	AdamDU Data Collection Program
700660289.....	Calibration certificate

## Key Accessories



### AdamDU Data Collection Program

AdamDU offers several useful functions such as graphing, statistical analysis, and data export to XML, CSV, HTML and Text files, or directly to Windows® applications including Microsoft® Excel, Microsoft® Word or the Windows® Clipboard. With support to accept and manage up to 8 balances or scales simultaneously, AdamDU is the best choice in data collection software for a range of applications.



### Labels - 800 per Roll

One 50mm-wide roll provides 800 labels for customized label printing functionality. Labels can be designed using the PC software included with Adam Equipment label printing indicators.

Supplied By: